




www.tuneyourengine.com

1996 - 1999 Acura Integra ECU Diagram



Connector A

Pin #	Name	Signal Type
A8	VTEC Solenoid Valve	Analog
A10	Power Ground	Ground
A20	Ignition Control Module	RPM
A23	Power Ground	Ground

Connector C

Pin #	Name	Signal Type
C15	VTEC Pressure Switch	Analog
C18	Vehicle Speed Sensor	Speed

Connector D

Pin #	Name	Signal Type
D1	Throttle Position Sensor	Analog
D2	Engine Coolant Temperature Sensor	Analog
D3	MAP Sensor	Analog 0.32V @ -13.9 PSI 4.84V @ 10.94 PSI
D5	Brake Switch	Analog
D7	Primary O2 Sensor	Analog
D8	Intake Air Temperature Sensor	Analog
D14	Secondary O2 Sensor	Analog