

Global

Help
Display Setting
Display Map
Display Menu
Display Navigation
Display Audio Screen
Display AC Screen
Display Information
Mobile Phone
Back / Backward
Next / Down
Previous / Up
Return / Cancel
OK / done
Delete
What time is it?

Navigation

How long to the destination?
Tell me the arrival time to the destination.
How far to the destination?
Register the current location
Save Current Location
Map Legend
Location

Navigation

Display Current Location
Display North Up
Display Heading Up
Display Zoom In
Display Zoom Out
Display 50 Metre Scale
Display 500 Metre Scale
Display 5 Kilometre Scale
Max Zoom In / Out
Go Home
Traffic Event List

Display / Hide / Find Nearest
Bank ATM
Hospital Post Office
Hotel fast food
Restaurant Shopping
Car Park Park and Ride
Rest Area TMC

Climate Control

Climate Control Full Automatic (22°C)
Climate Control Automatic
Climate Control On / off
Air Conditioner On / off
Climate Control Fresh Air
Climate Control Recirculate
Climate Control Vent
Climate Control Bi-Level
Climate Control Floor
Fan Speed Up / Down
Fan Speed # (#: 1-7)

Temperature

Temperature # Degrees
Temperature Up / down
Temperature Max Hot / cold

Radio

Audio On / off
Radio On / off
Radio FM1 / FM2
Radio AM Medium Wave / Long Wave
Radio # FM (#: 87.50-108.00)
Radio # AM Medium Wave (#: 531-1602)
Radio # AM Long Wave (#: 153-281)
Radio Seek Up / Down
Radio Next Station
Radio Preset # (#: 1-6)
Radio FM Preset # (#: 1-6)
Radio Auto Select
Radio Scan

CD

CD Play
CD Play Track # (#: 1-30)
CD Skip Forward / back
CD Track Random / Repeat / Scan
CD Normal Play
CD Track List

Card

Card Play
Card Play Track # (#:1-30)
Card Skip Forward / back
Card Track / Folder /Artist / Album
Random / Repeat / Scan *
Card Normal Play

